

Assembly WOW! - A WORLD OF WORMS

Contents:

WOW!© 75 x 90 x 90

4 Posts

14 Boards

2 Baton Boards

2 Grooved Boards

1 Observation Panel

1 Cover for Observation Panel

2 Plastic Slats

1 Compost Duvet,

1 Lid

Contents:

WOW!© 45 x 60 x 60

4 Posts

7 Boards

2 Baton Boards

2 Grooved Boards

1 Cover for Observation Panel

1 Observation Panel

2 Plastic Slats

1 Lid

Window On Worms

For a long life place your WOW!s in a well-ventilated position. Please place a flat stone, a piece of slate or a Post Slipper (see Website) under each post when in use

- 1. Slide a groove of a corner post over one end of a board.
- 2. Take a second corner post and slide it over the other end of the board.
- 3. Repeat to form a square from 4 posts and 4 boards.
- 4. At this stage chose the side where you need the window and insert the UV Polycarb Panel down the posts on the side chosen. This panel should have a Grooved Board above and below. If you are assembling the smaller WOW! you will need to use a Grooved Board on the bottom layer.
- 5. Continue to place the Boards between the posts, keeping the Baton Boards for the top layer. Baton Boards go opposite to each other with the baton facing inwards and at the top.
- 6. Place the Lid to rest on the Baton Boards.
- 7. Slide the Plastic slats one each side of the Observation Panel in the grove facing the front.
- 8. Next, slide the Observation Cover down the posts on the **outside** to rest on the Plastic Slats.